


# Operating and maintenance instructions

BLÜCHER Domestic® floor drains in stainless steel



## Comprising:

Floor drains for concrete/  
tiled floors, type nos.: 102, 110, 111, 114, 140, 150,  
151, 160, 161 and 181.

Floor drains for flexible sheet  
flooring, type nos.: 202, 210, 211, 214, 240, 250,  
251, 260, 261 and 281.

Floor drains for liquid  
membrane, type nos.: 302, 310, 311, 314, 350, 351,  
355, 360, 361 and 381.

Floor drains for  
sheet membrane, type nos.: 312, 313, 352 and 353.

Water trap, type nos.: 502 and 525.



## For the owner:

BLÜCHER Domestic® floor drain in stainless steel AISI 304 or optionally AISI 316L has been installed. The floor drain has been approved in accordance with the international standards as to flow capacity and self-cleansing.

## Prior to starting use:

- Check that the drain has been cleaned leaving no concrete spills etc.
- Check that the water trap has been installed.
- In vinyl floors check that the clamping ring has been well fixed.

## Normal operation:

BLÜCHER Domestic® floor drain in stainless steel has a removable water trap with excellent self-cleansing capabilities. In case of many impurities it may be necessary to clean the water trap at appropriate intervals.

## Cleaning:

- Loosen the screws in the grating (2 or 3 screws). Remove the grating and the water trap.
- Clean the water trap with detergent as necessary.
- Make sure that lubricant has been applied to the sealing ring of the water trap. Install the water trap applying a light pressure and twisting the water trap down to the stop ring in the drain. To avoid bad odours, make sure that the sealing ring of the water trap fits tightly to the drain.
- Replace the grating and tighten the screws.

## Technical data:

Specification of the product range and technical information are available as catalogues.

## BLÜCHER

Pugdølvej 1 . DK-7480 Vildbjerg . Denmark

Tlf. +45 99 92 08 00 . Fax +45 99 92 08 30

www.blucher.com . mail@blucher.dk