

# Safety alert – BLÜCHER dimpling jaws

## Important information concerning dimpling jaws

### Risk of injury due to insufficient maintenance and improper use

Dimpling jaws for pressing projections on BLÜCHER® EuroPipe are subject to natural wear and require regular maintenance. Incorrect use will accelerate the wear, and in the end the wear will result in cracks in the pressing contour.

In exceptional cases dimpling jaws with cracks from wear or other damage prior to use can break and pose a risk of injury due to flying fragments. The risk of injury is increased in instances of incorrect or improper use (for instance misaligned (tilted) pressing jaws, etc.).

For your own safety, we recommend that you make absolutely sure that you comply with the following safety instructions and inform all employees concerned accordingly:

1. Dimpling jaws must be checked regularly by the user before and after every use for cracks in the pressing contour.
2. If cracks can be seen, the dimpling jaw must be deemed unfit for use immediately. After incorrect or improper use, the dimpling jaw must no longer be used.

As part of our responsibility as a supplier of dimpling jaws, we should like to draw your attention to the fact that the risks outlined above may also be encountered when using dimpling jaws from other manufacturers. If you are in any doubt, please contact BLÜCHER.